


14.3 Sewer Network

14.3 Sewer Network

The Sewer Network Sub-Module maintains the information regarding the sewer networks of the city.

14.3.1 Navigation to Sewer Network

- Open the sidebar and click on 'Utility IMS' to expand.
- Select the Sewer Network



- This redirect to Sewer Network

Overview:

The Sewer Network Page lists all the attribute records stored in the module and provides different Filters, Actions and Tools that can be used according to the requirements. The For more details (refer to section 5 Filters, section 6 Actions and section 8 Tools).

Sewer Network

Export to CSV Export to Shape File Export to KML Show Filter

Show 10 entries

Code	Road Code	Location	Length (m)	Diameter (mm)	Treatment Plant	Actions
S000136	R000663	side	200.6	200	Municipality WWTP	    
S000135	R000662	middle	100.62	450	Municipality WWTP	    
S000134	R000655	middle	101.5	300	Municipality WWTP	    
S000133	R000650	middle	200.08	450	Municipality WWTP	    
S000132	R000649	middle	102.49	300	Municipality WWTP	    

Figure 14- 10 List of Sewer Network

- The location should be:
 - Middle – if the sewer network is in the middle of the road,
 - Side - if the sewer network is on either the right or left side of the road

Note:

- Deletion of sewer data is not permitted when it is associated with building data.
- Deletion of sewer data is not permitted when it is associated with sewer connection.

Revision #1

Created 4 February 2025 06:04:58 by Bookstack Editor

Updated 6 February 2025 07:31:29 by Bookstack Editor